

Usage Rating for Endurequip Hoists

Lifts Per Day	Average Loading on Hoist as percentage of Capacity			
	30%	50%	75%	100%
10 +	Extreme	Extreme	Extreme	Extreme
7 - 10	Heavy	Heavy	Extreme	Extreme
4 - 6	Medium	Heavy	Heavy	Heavy
3	Low	Low	Medium	Medium
1	Low	low	Low	low
Lifts per Day = Average number of lifts, based on 5 days a week, 50 weeks of a year.				
Average Loading = 7.5 tonne hoist lifting 2.5 tonnes per post is operating at 33% capacity. = 5 tonne hoist lifting 2.5 tonnes per post is operating at 50% capacity.				

Owners of the hoists are required by Australian Standards 2550.9 to carry out routine servicing.

Routine servicing is defined in two ways:

- Full Services (Annual Services) to be completed by a "suitably qualified person". (ie. someone trained By Endurequip.)
- Minor Services can be completed by a "suitably competent person". (ie. A responsible person, within the company, trained by Endurequip Services or their Authorised Repairer in fault detection, servicing and record keeping.

Management must ensure the following:

- Pre-operational checks are carried out
- A suitable maintenance program is in place that suits the usage of the hoists.
- Maintenance records are kept of all services, significant repairs and damage.

"Low" or "Medium" usage: Full service at 12 Monthly Intervals completed by Endurequip Services or an Authorised Repairer + 3 Monthly Minor Services by someone within your company.

"Heavy" usage: Full service at 6 monthly intervals by Endurequip Services or an Authorised Repairer + 3 Monthly Minor Services by someone within your company.

"Extreme" usage: Full service at 3 monthly intervals by Endurequip Services or an Authorised Repairer .