

CHOOSING CORRECT BULBS FOR YOUR CONTROL CABINET

When replacing the bulbs on your Portalift Control Cabinet you need to match the voltage and wattage to the transformer that powers it.

Turn off the power and remove the 3 phase plug from the wall socket.

Undo the 4 nuts that hold the cabinet top. Carefully, turn it over and look at the transformer that the bulb pushes into to.



In this case, the correct bulb is
6v 1.2w.

The pilot light transformer is connected to the lid of the Control Box.

Turn the lid back over. Bolt it back onto the cabinet. Insert correct bulb.
If a new bulb does not correct the problem then the transformer may need replacing.

Contact your Endurequip Service Technician to order a new pilot light unit.

ENDUREQUIP

Mb: 0431 715 702

Ph: (07) 3267 3558

service@endurequipservices.com.au

www.endurequipservices.com.au for helpful tips on Portalift hoists